# E-lens APEX Study Plan

E-lens teams







# **HOBBC** experiments at 255 GeV


- Test of lattice
  - Dynamic Aperture (in operations with 1 BB collision)
  - Polarization and polarization lifetime (in operation)
  - Phase advance IP8 to e-lens (setup or APEX)
- Effect of e-beam on p-beam tune distribution (BTF)
  - Change in distribution with  $I_{\rm e}$  and  $\sigma_{\rm e}$
  - BB footprint compression with e-lens
- Max beam-beam parameter  $\xi_p$  with 2 BB collisions and with and without e-lens
  - Need maximum available  $\xi_p$ , i.e.  $N_b \ge 2.5 3.0 \times 10^{11}$  with  $\epsilon_n = 2.5 \ \mu m$
  - ~28x28 bunches, short stores (~10 min)
     get data for plot like this (much fewer points) =>
- Measurement of BB Resonance Driving Terms
- Test of beam stability









# 2017 lattice (yellow)



# eBSD Alignment (Yellow) -0.3 mrad












# eBSD Alignment (Yellow)


Angle values in the Yellow alignment scan:

A. hor scan: 0.0, +0.1, +0.2, -0.1, -0.2, -0.3, -0.4, -0.5 mrad At each step x-y position optimization with LISA. Set to -0.3 mrad.

B. ver scan: 0.0, +0.1, -0.-1, -0.2 mrad (see increased losses at +0.1 and -0.2 mrad) At each step x-y position optimization with LISA.

Set to 0 mrad













#### **BTF**











### **Summary**

- 1. New store ramp pp17-elens0 instead of pp17-s0. Acceleration ramp unchanged. Measured optics for pp17-elens0 (Yellow should have multiple of 180 deg between IP8 and Yellow e-lens).
- 2. Turned on warm solenoids in both e-lenses.
- 3. Turned on electron beam in both e-lenses (~500 mA). Immediate signal in Blue and Yellow eBSD.
- 4. Position and angle alignment scan with the Yellow lens:

Angle values in the Yellow alignment scan:

4A. hor scan: 0.0, +0.1, +0.2, -0.1, -0.2, -0.3, -0.4, -0.5 mrad At each step x-y position optimization with LISA. Set to -0.3 mrad.

4B. ver scan: 0.0, +0.1, -0.-1, -0.2 mrad (see increased losses at +0.1 and -0.2 mrad) At each step x-y position optimization with LISA.

Set to 0 mrad

5. Current scan with BTF at final angle and position values (480, 390, 290, 190, 90 mA)











