
CRYOGENIC OPERATIONS

Tony Nicoletti March 6, 2002

FAILURE HOUR BREAKDOWN



Does not include insulating vacuum problems which delayed cooldown.

ADDRESSING THE ISSUES

- Valve Box Insulating Vacuums
 - Replace defective valve casings at 6 o'clock Blue and Yellow Valve boxes.
 - Replace all that have not been replaced already
 - 75 valve casings
 - Eliminate corroded welds that degraded insulating vacuum

REFRIGERATOR OPERATIONS

- Burst Disk Switchable Valve
 - Isolate a burst disk for replacement while simultaneously bringing another on-line.
- Fiber Optic cable for communications between cryo control and refrigerator, compressor room.
- Upgrade CRISP I/O system
 - Improved control features
 - Improved security features
- Refrigerator Temperature Instrumentation
 - Easier to replace sensors
 - Allows for expansion
- Refrigerator Vacuum Instrumentation

Cryo Turbo Expanders

- Turbine refurbishing
- Adding heater to warm up turbines
- Turbine skid refurbishing
- Adding pressure instrumentation to help diagnose problems
 - Precursor to instrumentation overhaul



RING ELECTRICAL

- Moving I/O racks at 9Q3, 9Q6, 10Q3, 10Q6 to 10:00 service building
- Power Lead Heaters
 - Failure alarms on CQS lead Heaters
 - Redesign of Snake Lead Heaters

2002 UPGRADES

- Helium Reliquefier at 1006B
 - Maintain Liquid Helium Dewars cold during shutdowns
 - Can hold approximately 3 million scf of Helium
 - With additional warm tanks, this eliminates the need for off site storage
 - Completed this calendar year



WARM HELIUM STORAGE TANKS

- Eventual capacity to store3.8 million scf of warmHelium
- With the Helium liquefier operational, the entire inventory can be stored on site during RHIC shutdowns



NITROGEN PRECOOLER

- Maintain the ring at 80-100K during shutdowns
- Reduce cooldown time by 2 weeks
- Keep the system free of contaminants
- Eliminate stresses associated with thermal cycling
- Due on site in December, 2002. Available for next RHIC shutdown

FUTURE UPGRADES

- TURBINE SKID I/0
 - Replace pneumatic system with electronic control.
 - Integrate into process control system
 - Improved problem diagnosis and troubleshooting
- COMPRESSOR ROOM I/O
 - Integrate into process control system
 - Improved problem diagnosis and troubleshooting
- Become aware of problems before they shut equipment off.