

Concurrent Operation of RHIC (Ions or PP) and NSRL

- Review of the switching operations that allow us to run various programs simultaneously.
- Examples of what we have done and can do.
- Complications that have arisen.

Switching Operations

- Pulse-to-Pulse Modulation (PPM)
- Context Switching (PPM on demand)
- Mode Switching (non-PPM)


PPM Switching


- This is the switching of device setpoints between Booster or AGS magnetic cycles (pulses). The setpoints are thereby modulated on a pulse-to-pulse basis; hence the name “ppm”.
- Four different sets of setpoints are possible for both Booster and AGS. One therefore can have four “Users” of accelerator devices, each user specifying a set of setpoints.

The SuperCycle


- The users need a driver; this is the function of the SuperCycle.
- One can have multiple Booster users on a given supercycle, but only 1 AGS user.
- Each Booster user can have one or more magnetic cycles.
- The AGS user can have just one magnetic cycle.

Examples





Linac	LGE									
Tandem	TU1	TT0	TT0	TT0	TT0	TT0	TBE			
Booster	TT1									
	BU1	BPP	BPP	BPP	BPP	BPP	BU2		BGE	
	BPP	BFR	BFR	BFR	BFR	BFR	BPP			
	BFR	BT0	BT0	BT0	BT0	BT0	BFR			
	BT0	BT1	COG	BT3	COG		BT0			
Ags							BT1			
							BT4			
	AU1	AFR								AGE
	APP	AT0								



Linac Tandem	TT1 TT0	TT0	TT0	TT0	TBE		TT1 TT0	TBE	LGE	
Booster	BU1	BPP	BPP	BPP	BPP	BGE	BU4	TU1	BGE	
	BPP	BFR	BFR	BFR	BFR		NSRL			
	BFR	BT0	BT0	BT0	BT0		BPP			
	BT0	BT1	COG	COG	COG		BFR			
		COG					BT0			
Ags	AU1	AFR								AGE
	APP	AT0								

Context Switching

- Sometimes we want to switch from one supercycle setup to another on demand.
- This is called “Context Switching”, “Pulse Stealing” or “PPM on demand”.
- Different supercycles are stored in tables that can be invoked on demand.
- For commissioning different modes of operation or for regular toggling back and forth between two beam operations programs.

Supercycle Pulse Manager

SCPulseManager

Setup

Help

Wed Jan 14 11:10:19 2004

Default

Statistics since Wed Jan 14 11:09:48 2004
 Table A: 0 Table B: 6
 Table C: 0 Table D: 0

Ags Cycle					33581	33582	33583	33584	33585	33586
Table	-	-	-	-	B	B	B	B	B	B

Default SuperCycle

Table B

Name	Length(s)	Booster	Ags	Description
wsrgz	5.4	U1	U1	

System Default PPM User: RHIC_Au_U1

Pulse Stealing

Table	Pulses	Count	Name	Length(s)	Booster	Ags	Description
A	Take 1	0	aef	5.4	U1	U3	
B	Take 1	0	wsrgz	5.4	U1	U1	
C	Take 1	0	Silica	5.4	U3	U2	
D	Take 1	0	pwtest35	5.4	U1/U4	U1	RHIC_Au_U1

Round Robin

Round Robin Off

A Pulses	B Pulses	C Pulses	D Pulses
0	0	0	0

Mode Switching

- We use mode switching to switch devices that cannot be switched on a pulse-to-pulse basis, such as:
 - BTA and ATR magnets;
 - Booster and BTA stripping foils;
 - AGS Injection Kicker;
 - Tandem and TTB elements;
 - R-line (NSRL) elements;
 - AGS Warm and Cold Snakes.

Mode Switching Experience

- RHIC Gold \Leftrightarrow AGS Proton SEB
- RHIC Gold \Leftrightarrow Deuterons \Leftrightarrow PP
- RHIC Gold \Leftrightarrow Nsrl Ions
- RHIC Gold \Leftrightarrow AGS PP Setup
- RHIC Copper \Leftrightarrow AGS PP Setup
- RHIC PP \Leftrightarrow AGS Cold Snake Setup
- Nsrl Protons \Leftrightarrow Nsrl Iron (Titanium)

FY04 Program

Week no.	Starting Monday	Actually !	Description
1	1-Dec-2003		5-week RHIC Startup
2	8-Dec-2003		
3	15-Dec-2003		
4	22-Dec-2003		
5	29-Dec-2003	Dec.31, 2003	
1	5-Jan-2004		14-week RHIC Au-Au run
2	12-Jan-2004		
3	19-Jan-2004		
4	26-Jan-2004		
5	2-Feb-2004		
6	9-Feb-2004		
7	16-Feb-2004		
8	23-Feb-2004		
9	1-Mar-2004		
10	8-Mar-2004		
11	15-Mar-2004		
12	22-Mar-2004		
13	29-Mar-2004		
14	5-Apr-2004		
1	12-Apr-2004		5-week polarized proton run
2	19-Apr-2004		
3	26-Apr-2004		
4	3-May-2004		
5	10-May-2004		
	17-May-2004		
	24-May-2004		
	31-May-2004		
	7-Jun-2004		
	14-Jun-2004		



LINAC turns
on

Booster/AGS
polarized
proton run


NSRL

BLIP

TAPE (Tool for Automated Procedure Execution)



Gold and PP Mode Switch



File	PPM	Mode	View	Lists	Procedures	Help
▼					Gold-PP	- ?
					Contact LINAC/PP	P ?
					Contact NSRL	P ?
					Make ELog Entry	P ?
					Inhibit Tandem Beam	P ?
					Inhibit LINAC beam	P ?
▶					Verify State	- ?
					Save State	C ?
					Set Intermediate State	P ?
▶					Save Archive	- ?
▶					Set ARC8 Magnet	- ?
▶					Set ARC20 Magnet	- ?
					Turn Off ARF.LOCAL_OSC.ST	P ?
▶					TurnOnAgsIpmLeak	- ?
▶					A5 Injection Kicker	- ?
▶					Set H-minus Injection Foil	P ?
▶					Set BTA Foil	- ?
▶					Set XFMR Gains	- ?
					Set H10.V_CYCLE	P ?
▶					Set BTA Magnets	- ?
▶					PPM devices	- ?
					Set AGS Calibrate	P ?
▶					Verify H-minus Injection Foil	- ?
▶					Verify BTA Foil	- ?
					Set BTA.MW_GAIN to HIG	P ?
▶					Turn E20 snake on	- ?
					Switch Supercycle Table	P ?

Run

Retry

Pause

Cancel

(04:26:24) PP_Gold loaded successfully
 (04:28:40) Gold_PP loaded successfully

File	PPM	Mode	View	Lists	Procedures	Help
					Set Intermediate State	P ?
▶					Save Archive	- ?
▶					Set ARC8 Magnet	- ?
▶					Set ARC20 Magnet	- ?
					Turn Off ARF.LOCAL_OSC.ST	P ?
▶					TurnOnAgsIpmLeak	- ?
▶					A5 Injection Kicker	- ?
▶					Set H-minus Injection Foil	P ?
▶					Set BTA Foil	- ?
▶					Set XFMR Gains	- ?
					Set H10.V_CYCLE	P ?
▶					Set BTA Magnets	- ?
▶					PPM devices	- ?
					Set AGS Calibrate	P ?
▶					Verify H-minus Injection Foil	- ?
▶					Verify BTA Foil	- ?
					Set BTA.MW_GAIN to HIG	P ?
▶					Turn E20 snake on	- ?
					Switch Supercycle Table	P ?
▶					Set State	- ?
					Set Default Ppm User to 4	P ?
					Set Booster to Repeat cycle	P ?
					Verify AGS main magnet field is stable	P ?
					Turn ON ARF.LOCAL_OSC.ST User4	P ?
					Load BMM cycle User 3	P ?
					Turn ON ARF.LOCAL_OSC.ST User3	P ?
					Check LTB beamstops	P ?

Run

Retry

Pause

Cancel

(04:26:24) PP_Gold loaded successfully
 (04:28:40) Gold_PP loaded successfully

00:00

08:00

16:00

24:00

Silicon in Booster for NSRL



Gold in Booster and AGS for RHIC



Polarized Protons in Booster and AGS



Protons for BLIP



00:00

08:00

16:00

24:00

Iron in Booster for NSRL



Gold in Booster and AGS for RHIC



Polarized Protons in Booster and AGS




Protons for BLIP




FY05: RHIC (Copper and PP) and NSRL (Ions and PP)

- Copper for RHIC \Leftrightarrow PP for AGS.
- PP for RHIC \Leftrightarrow AGS Cold Snake development.
- PPM: NSRL & RHIC PP.
- Proton-Titanium mode switch for NSRL.


PP to AGS for RHIC




Complication: Booster Dwell Field Matching




**Possible PP & NSRL PPM, but
power too high for PS:**




So...use a longer supercycle for PP and NSRL PPM:




Or Toggle between modes:



and:



Or no Booster cycles for AGS with the NSRL cycle:



Complications:

- Required spin resonance correction depends on AGS repetition period.
- If the NSRL cycle is taking PP, the accounting of spin up and down for AGS requires some care.

Other Complications:

- Linac timing is very sensitive to the placement of supercycle events.
- Sinusoidal timing of HEBT dipole for 200 MeV polarimeter requires careful placement of supercycle events.
- Setting of BM2 between source and RFQ depends on whether NSRL is taking PP or not.
- NSRL extraction bump affects BTA trajectory for PP to RHIC.