

Instruction for Installing Deep Memory Scope (Agilent 54624a) Remote Control and Monitor program.

This program allows users to monitor and control the Agilent 54624a deep memory scope remotely via the Microsoft Internet Explorer Web Browser. The user PC must be behind the firewall (such as 104, 108 network etc.) or access from home via the Crypto Card.

1. Download and install the National Instrument LabView Run time driver from this web site. The program name is LVRunTimeEng.exe.
2. Start the IE browser. Type <http://qdcs17.pbn.bnl.gov/ag54624a.htm> A scope panel will appear.
3. Right click the mouse once to "Request control of VI". You can control the scope after the web server honors the request. Only one user can control the scope, all other users can monitor the screen.

Note: The web server qdcs1.pbn.bnl.gov computer is located at Wing Louie's Office. This is an interim webserver, a permanent server will be setup at 1004B.