

Brookhaven National Laboratory

Minutes, LEReC High Energy Extraction Meeting

2017-03-09

Overall Extraction Line – Discussed as follows:

Statements:

- Model was corrected so dump line is parallel to RHIC cryostat (19.8 degree bend)

Questions:

- 1) What is extent of bake-out region along extraction / dump line?

Answer: Bake-out will go up to second valve of extraction line.

- 2) What is extent of magnetically shielded region?

Answer: All of extraction line shall be magnetically shielded where possible. Open spools / drift sections, transitions, and bellows shall be shielded by wrapping magnetic shielding foil around tubes, etc. Contact George for details of magnetic shielding.

- 3) Are Tees, Bellows, or Valves shielded for beam current?

Answer: Tees, Bellows, and Valves need not be shielded, but can if possible.

- 4) Is Laser Wire Scanner a priority?

Answer: Laser Wire Scanner is a good opportunity since it is a R&D device and can provide valuable information during CW that other devices can do only in pulsed. Use only if it can easily fit. Possibility of moving corrector magnet and/or solenoid to fit it. Possibility of placing it in 2nd open space, but minimal concerns about back-scatter striking it. Determine size and placement, then contact Jorg to verify changes if necessary.

Extraction Line Components, Section 1 – Discussed as follows:

- 20° Dipole (large gap, 2.5" tube)
- Gate Valve #1
- Shielded Bellows
- Profile Monitor #1 (new, details needed from Toby)
- Tee / Ion Pump #1
- Shielded Bellows
- BPM #1 (new)

Minutes_LEReC-HE-Extraction-2017-03-09-Extraction-2017-02-08

Minutes, LEReC High Energy Extraction Meeting

- Solenoid #1
- Corrector Magnet #1
- Tee / Ion Pump #2
- Shielded Bellows
- Zero Length Adapter Flange (step changes in beam tube are OK)
- Profile Monitor #2 (existing – in use in booster now; move close to Dipole, install rotatable bellows between monitor and Dipole)
- Zero Length Adapter Flange

Questions:

- 1) What is the chamber size of L.E. PM?

Answer: Can be answered by Toby.

- 2) Is the Tee bolted directly to L.E. PM #1?

Answer: Can be answered by Toby and Mike Mapes.

- 3) Will Ion Pump magnets affect e-beam?

Answer: Yes, Ion Pumps should be small and on an elongated Tee so field at beam is less than 1 Gauss. Design similar to DC Gun Test.

- 4) Shielded Bellows interference with BPM #1, can BPM be moved?

Answer: Yes, it is OK to move BPMs and Corrector magnets. OK to move Solenoid by no more than ten (10) centimeters.

- 5) Should there be a bellows after BPM #1?

Answer: OK to put bellows inside solenoid. Try to minimize support points. More support points means less / shorter magnetic shielding sections.

- 6) Should PM #2 be bolted directly to 20 degree beam tube as shown?

Answer: Should be bellows if possible.

Brookhaven National Laboratory

Minutes, LEReC High Energy Extraction Meeting

Extraction Line Components, Section 2 – Discussed as follows:

- 20° Dipole
- Quad #1 (small diameter from ERL)
- Gate Valve #2
- Corrector Magnet #2
- BPM #2 (existing)
- DCCT
- Conical Reducer (step changes in beam tube are OK)
- Bellows
- Ion Pump / Tee #3
- Conical Reducer (step changes in beam tube are OK)
- Spool

Questions:

- 1) Does the Gate Valve hang off the dipole beam tube w/o any other support?

Answer: Can be answered by Mapes.

- 2) Interference of beam pipe with Quad #2, how can this be corrected?

Answer: Leave ERL Quad as is and use smaller 2.0 inch diameter beam tube inside magnet.

- 3) Interference of Corrector Magnet #2 with BPM #2, how can this be corrected?

Answer: It is OK to move BPM. Verify new position with Jorg.

- 4) ERL Extraction DCCT is missing; where is it?

Answer: Nobody knows. Check with Toby or Dan Lehn.

- 5) Is the Tee bolted directly to L.E. PM #3?

Answer: Can be answered by Toby and Mike Mapes.

- 6) Interference of Corrector Magnet #2 with BPM #2, how can this be corrected?

Answer: It is OK to move BPM. Verify new position with Jorg.

- 7) Interference of Corrector Magnet #2 with BPM #2, how can this be corrected?

Answer: It is OK to move BPM. Verify new position with Jorg.

Brookhaven National Laboratory

Minutes, LEReC High Energy Extraction Meeting

Extraction Line Components, Section 3 – Discussed as follows:

- Ion Pump / Tee #4
- Profile Monitor #3
- Reducer
- BPM #3 (on 5" diameter pipe)
- Bellows
- FCT
- Quad #2 (large diameter from ERL, over-focus quad)
- Ceramic Break (large diameter from ERL)
- Dump (from ERL)

Questions:

- 1) Is the Tee bolted directly to L.E. PM #3?

Answer: Can be answered by Toby and Mike Mapes.

- 2) Does the Ceramic Break need to be shielded?

Answer: Yes, ceramic break should be shielded.

- 3) Are we definitely using ERL Over-Focus Quad before the Dump?

Answer: Yes.

Other Discussion:

Questions:

- 1) Is the BLM array around the Dump being used, if so is it interlocked for MPS?

Answer: Probably will not be interlocked into MPS; Sergey will look into and give OK for using BLM array.

- Action Items:

- J. Fite – Determine correct component gaps and beam tube diameters.
- J. Fite – Determine status of all beam components and beam tubes.
- J. Fite – Develop Installation schedule.