

Summary of Working Group II

Chamber Coating and Treatment

Participants:

Michel Chanel	CERN
Ping He	BNL
Dick Hseuh	BNL
Roberto Kersevan	ESRF
Yulin Li	Cornell
Mike Seidel	DESY
Peter Seidl	LBNL
Ysuke Suetsugu	KEK
Robert Todd	BNL
Daniel Weiss	BNL

....

Chamber Coating

TiN

NEG

Others

Chamber Treatment

Baking, Vacuum Firing

Cleaning

Chamber Coating – TiN

Goal: To reduce SEY

Impurity and coating pressure is critical to SEY

BNL/SNS Coating @ 5 mTorr \Rightarrow SEY 1.5-1.8 due to rougher surface

BNL/SNS Coating @ 1.5 mTorr \Rightarrow SEY > 1.9 due to smooth surface

SEY of St St \sim 2.2


Similar is observed for other surfaces, Cu and NEG

Measure SEY for each coating parameters

Facilities @ CERN, KEK, SLAC

PSR experience with TiN coated chamber?

Beam scrubbing of mC/mm^2 !



Chamber Coating – NEG (CERN + *ESRF* + Cornell)

To reduce SEY, ESD and provide distributed pumping

Low SEY of 1.1 - 1.3 after activation

SEY of < 1.7 (< 1.4 in SPS lab test) after saturation and after H₂O saturation.

As received: < 2.0

Other SEY data: ~ 1.1 after activation, 1.4 after saturation, 1.9 after overnight?

Coating parameters: 100C, $2e-2$ Torr Kr gas

or **300C coating** \Rightarrow rougher surface but more capacity between activation

NEG Surface is rougher on Al and smoother on SS

No bonding problem even on Al surface with $1 \mu\text{m Al}_2\text{O}_3$

Need consistent measurement of SEY from different lab on

Rough vs. smooth NEG surface

300C vs. 100C coatings

Coatings on SS, Al, Cu, Be...

Chamber Coating – NEG (contiuene)

Optimum coating thickness: 1 – 1.5 μm (adhesion?)

Flaking of coating if surface is contaminated.

No impurity during coating

No pumping with a few percent of O loading (Cornell, ESRF)

Enough capacity for over 10 air vent/activation cycles (depending on T)

Activation temperature of NEG

100C – observed some activation (Cornell)

180C – ESRF

250C – RHIC

$\leq 300\text{C}$ – LHC LSS; LEIR

Use ion pumps to remove H_2 during re-activation (ESRF)

Impedance is better than Stainless Steel but worse than Aluminum

50 $\mu\Omega\text{-cm}$ is OK for ESRF but not for KEKB

Chamber Coating - Others

Palladium (Pd) over layer on NEG to prevent H₂O and oxide diffusion into NEG during activation, therefore preserve the NEG capacity for H₂.

Pd pumping of H₂/CO reversible by activation @ 100C. Easy to sputter, expensive cathode

Other types of coating - Diamond-like graphite coating

Low SEY but may be difficult to implement for long chambers

Plans at various labs

Cornell – need high H₂ capacity down to e-13 Torr (Pd over layer?)

ESRF – will test Pd over layer coating in the near future

KEKB – may test NEG on a straight section for SEY (difficulty to activate)

Compatible with Cu SEY? not advantage from photon scrubbing due to narrow band

PEP-II – TiN coating of straight section chambers

LHC LSS – baking @150C, activation @200C - 300C with 0.5mm SS foil heaters

LEIR – NEG coating of SS + Quads, activation @300C

GSI – NEG coating of SIS dipole chambers; low desorption material

Chamber Treatment

Vacuum Firing to reduce H₂ but not helping ESD... (Uppsala)

Universal outgassing data base for insulators... will be beneficial for the community (Uppsala +...)

No electro-polishing after vacuum firing – re-loading of H₂

GDC by Ar + O₂ or He + O₂ is not suitable for heavy ion machine, due to the release Ar and He during beam scraping.

Cleaning:

DI water high pressure wash, then EtOH wipe, no acid etching (Cornell)

DI water rinse till the water passes the conductance test or optical particle counting (Tesla)

High pressure detergent + water rinse, EtOH wipe (RHIC)

Cu chambers – chemical polishing (KEKB)

Test every chamber vs. Test a few chambers vs. Test all special chambers

Thin foil heaters + insulation (~mm) for bakeout and NEG activation of LHC LSS and Expt Pipes

