

# Chromaticity/Emittance Issues

---

Steve Tepikian

- Chromaticity at Injection and Storage
- Chromaticity during the ramp and Feedback
- Transverse Emittance (IPMs)
- Summary

# Chromaticity

---

- Chromaticity causes tune variations with momentum

$$\Delta\nu = \xi_1 \frac{\Delta p}{p} + \xi_2 \left( \frac{\Delta p}{p} \right)^2 + \xi_3 \left( \frac{\Delta p}{p} \right)^3 + \dots$$

- Momentum variation is determined by the radial beam shifts:

$$\frac{\Delta p}{p} = \alpha \frac{\Delta R}{R}$$


- Where  $\alpha$  is the momentum compaction factor:

$$\alpha = \frac{1}{\gamma_T^2}$$

- With  $\gamma_T$  being the gamma-transition of the lattice.
  - *Can be obtained from the model engine.*


# Chromaticity

- Measure chromaticity at injection and/or flattop using ARTUS.
- Can also use PLL if active during measurement.
- Number of steps and maximum radial shift is adjustable.




- Fit the measured tunes vs momentum to a polynomial.
- This is a destructive measurement.
- At flattop, the beams must be **uncogged** and **no 200 MHz cavities**.

# Chromaticity Application




# Chromaticity

- Use the PLL tunemeter to measure the tunes
  - *Standard deviation of noise:  $2 \times 10^{-4}$  horizontal,  $0.8 \times 10^{-4}$  vertical*
  - *Data returned with 70 Hz rate*
  - *With **tune feedback** on, data signal delayed, including amplitude factor*
- Use a small radial jump,  $\approx 0.2$  mm, in 1 Hz sine wave.
- Calculate the chromaticities by sliding the data along at 70 Hz rate.
- Include error estimates for the chromaticities.
- Feedback the chromaticities to correct the sextupoles, weighted by errors.
- At start of ramp,  $\Delta\gamma$  change is largest in 1/2 sec (snapback)



# Chromaticity Radial Modulation Data




# Emittance and IPMs

---


- Measured emittance sometimes larger than expected at storage
  - *Improved gaussian fitting of profiles this run*
  - *Horizontal IPMs at small  $\beta$  function locations*
  - *Need to fix some dead channels*
  - *Improve data synchronization as saved by logger system*
- IBS measurements were made with both Gold and Proton beams
- A good diagnostic for beam effects
  - *Drops in emittance may be due to beam scraping*
  - *Jumps in emittance can be traced to beam kicks*

# Emittance Growth Data





# BLM ring dataSumM data



# Summary

---

- A tool is provided to measure and correct chromaticities at injection and flattop
- Developing a tool to measure and correct chromaticities on the ramp using the PLL tunemeter
  - *Initial test to measure chromaticity on the ramp are encouraging*
  - *Requires improvements in PLL tunemeter system*
- Other methods to measure the chromaticity are being considered
  - *Chromaticity from decoherence data, etc.*
- Emittance measurement with IPMs provided a good diagnostic tool on beam performance