

# Jefferson Lab FY03 R&D Activities in Support of RIA

**J. Delayen, E. Daly, K. Davis, L. Harwood, A. Hofler, C. Hovater**  
**Thomas Jefferson National Accelerator Facility**

**RIA R&D Workshop**  
**Washington D. C. 26-28 August 2003**



**Thomas Jefferson National Accelerator Facility**



# JLab FY03 Tasks

## Low level rf control development

- Finalize and refine the RIA requirement document
- Develop a MATLAB model including cavity and rf system
- Explore effectiveness of electronic damping of microphonics

## Cryomodule measurements

- Perform measurements on SNS cryomodules
  - Microphonics
  - Lorentz and piezo tuner transfer functions
- Assess suitability of unmodified SNS cavities and CM for RIA
- Investigate minor modifications and optimize design of components



# Low Level RF Development Status

## Collaborations

- DESY and Cornell (Video Conferencing)
  - LLRF design comparisons
  - Vendor tool assessments
- SNS LLRF redesign

## MATLAB/Simulink Model

- Model for medium beta SRF cavity exists
  - Based on Simulink library for RF systems developed at TTF
  - Includes beam loading, klystron saturation characteristics
  - Operating Modes: Self-excited loop, Generator driven resonator
  - Proportional controllers: I/Q, Amplitude and phase
- Lorentz force detuning
- Incorporates measured data from SNS cavities



# Future LLRF Activities

**Develop and incorporate microphonics model using white noise process**

**Analysis of electrical damping of mechanical modes**

**Investigate reduction of microphonics with piezo tuner**

**Complete requirements document**



# Measurements on SNS Cryomodules

**Couplers**

**Tuners resolution and hysteresis**

**OK for RIA**

**Transfer functions**

- Lorentz (AM-FM)
- Piezo tuner

**Different from  
each other**

**Microphonics**

- Amplitude
- Frequency spectrum

**Suitability for RIA is an  
unresolved issue.**

**Vary from  
cavity to  
cavity**



# RF Power Couplers

## RIA Requirements

- ~20 kW CW, 10 MV/m

## SNS Prototype CM

- Good results at 100 kW CW & 9 MV/m
- Agreed with predictions



**Couplers shouldn't be a problem**


# Cavity Resonance Monitor

## Properties

- Generates a voltage proportional to instantaneous frequency deviation from a stable reference
- 50 db input dynamic range
- Selectable options
  - Gain 10Hz/V or 100 Hz/V
  - Low pass 1 Hz or 1 kHz
  - Bandpass 1 Hz to 1 kHz
- Portable

## Uses


- SNS
- CEBAF
- RIA (could be used for all)
  - Spoke cavity has been measured at ANL
  - Can be used to measure elliptical cavities at MSU




# Mechanical and Piezo Tuners

- ~1 Hz resolution and deadband for both the piezo and mechanical tuners.
- Tuner-generated microphonics are acceptable if ramping is slow.
  - Square step: microphonics equal to the tuner step
  - 10 msec ramp: microphonics reduces to  $<1/4$  of tuner step size

## Piezo tuner driving SNS M01-1



## Mechanical tuner driving SNS M02-3







# Microphonics: Probability Density

(Note: Slow drift has been removed)



## Baseline number

- SNS: 17 Hz
- CEBAF & RIA: <3.5 Hz
  - Usually achieved
  - Sometimes exceeded







## Substantial differences

- Between cavities
- Temporal



# Microphonics: Frequency Spectrum of RMS Amplitude




# Piezo Tuner Transfer Function: Reduce the microphonics using the piezo

## Methodology

- Sinusoidal voltage driving piezo tuner
- Ramp frequency & excite mechanical modes in succession

Substantial differences observed between cavities, (especially phases)

Cavity-specific data must be incorporated in LLRF model & control



# Lorentz Transfer Function (AM-FM):

## Use electronic damping to reduce microphonics


### Methodology

- Sinusoidal modulation of cavity field amplitude
- Ramp frequency & excite mechanical modes in succession

Substantial differences seen:

1) between cavities and 2) from piezo transfer function

Cavity-specific data must be incorporated in LLRF model & control



# Future Measurement and System Integration Activities

## Funded

- Continue measurements on SNS cryomodules (medium and high beta)

## Proposed

- Complete development of a LLRF control system suitable for a wide range of applications
- Perform measurements on other RIA cavities
- Perform an integrated test of a RIA driver cryomodule + RF system (original proposal)

